

STEPS TO CHANGE YOUR TFTP SERVER ADDRESS ON A CISCO 7940/60

1. Press the Check Box on your Cisco Phone 
2. Select Network Settings (option 3)
3. Press * * # to unlock phone
4. Scroll Down to "Alternate TFTP" (option 32): If "NO" press "YES".
(do not press "save" yet)
5. Scroll Up to "TFTP Server" (option 8). Press edit.
Enter the IP Address, **207.34.32.100** and press "VALIDATE"
6. Save first Screen and then save the second screen.
7. Allow the phone to refresh.

FOR MORE INFORMATION GO TO WWW.PRESSONE.NET/MANUALS.HTM
