

STEPS TO CONVERT DHCP TO STATIC IP ADDRESS ON CISCO 7940/60

1. Press the Check Box on your Cisco Phone 
2. Select Network Settings (option 3)
3. Press * * # to unlock phone
4. Scroll Down to "DHCP Enabled" (option 30): If "yes" press "NO".
5. Scroll Up to "IP Address" (option 6). Press edit.
Enter the IP Address and press "VALIDATE"
6. Scroll Down to "Subnet Mask" (option 7). Press edit.
Enter the IP Address and press "VALIDATE"
7. Scroll Down to "Default Router 1" (option 9). Press edit.
Enter the IP Address and press "VALIDATE"
8. Scroll Up to "TFTP Server" (option 8). If this field is not set press edit.
Enter the IP Address and press "VALIDATE"
9. Save first Screen and then save the second screen.

FOR MORE INFORMATION GO TO WWW.PRESSONE.NET/MANUALS.HTM
